



The following recommendations should be followed:

1. A free draining granular aggregate should be placed behind the StoneWall SELECT units in a 1:1 ratio of wall height to depth of the granular fill. All geogrid soil reinforcement will be placed in granular drainage fill.

2. The entire wall system including the wall base and geogrid reinforced zone shall be protected with a geo-textile fabric. See illustration. 3. A drainage system must be designed to relieve hydrostatic pressure from behind the retaining wall and provide for adequate flow of water as the water table changes.

4. Rip rap protection should be provided in front of the wall to protect the wall from scour, wave action, ice action etc. as required. StoneWall SELECT... another perfectly proportioned product from:



Innovative Concrete Design

Web Site www.selecticd.com Toll Free 800 / 394-4066