

NAME/COMPANY:

PHONE:


JOB NAME:

JOB #:

DATE:




ICD CORPORATION
INNOVATIVE CONCRETE DESIGN
3934 NORTH RIDGEFIELD CIRCLE
MILWAUKEE, WI 53211
(414) 962-4065
(414) 332-9678 FAX




A. INSTALLING SUCCESSIVE COURSES OF SWS UNITS

1. ENSURE THE DRAINAGE AGGREGATE IS LEVEL WITH, OR SLIGHTLY BELOW THE TOP OF SWS UNIT BELOW.
2. CLEAN DEBRIS OFF TOP OF UNIT.
3. PLACE SWS UNIT INTERLOCKING CLIPS.
4. MOVE SWS UNIT TO ENGAGE CLIPS AND ESTABLISH PROPER SETBACK.



B. FILL PLACEMENT AND COMPACTION

1. USE DRAINAGE AGGREGATE TO FILL OPENINGS IN AND BETWEEN SWS UNITS
2. PLACE DRAINAGE AGGREGATE BEHIND AND UP TO HEIGHT OF SWS UNIT TO CONTINUE WALL FACE DRAIN. INSTALL GEOTEXTILE IF REQUIRED.
3. PLACE AND COMPACT INFILL SOIL BEHIND WALL DRAIN.
4. COMPACT DRAINAGE AGGREGATE AND INFILL SOIL.



CONSTRUCTION SEQUENCE – STEP 3

PLACEMENT & BACKFILLING OF SWS UNITS

SEE DETAILS 099-011 TO 099-015